

# **INSTALLATION**

**REPLACEMENT**

**POTENTIOMETER**

## INSTALL MANUAL

This manual covers the replacement and installation of the potentiometer in Super Vac battery-powered ventilation fans.


*Please consult your potentiometer kit for parts.*



To view installation video, [click here](https://bit.ly/replacing-potentiometer). [bit.ly/replacing-potentiometer](https://bit.ly/replacing-potentiometer)

PARTS AND TOOLS

POTENTIOMETER WIRES




13MM SOCKET

9/64 ALLEN WRENCH

1/16 ALLEN WRENCH

### STEP 1:


Remove potentiometer knob.



Remove potentiometer knob by unscrewing with 1/16 Allen Wrench.

### STEP 2:


Remove rear cover.



Remove rear cover by unscrewing 6 screws with 9/64 Allen Wrench.

### STEP 3:


Disconnect potentiometer wires.



Unplug potentiometer wires. (Red, purple, and white wires) This plug usually is tucked into the back of the box.

### STEP 4:

Remove potentiometer.



Using a 13mm socket, remove the hex nut and lock washer holding in the potentiometer. With hex nut removed, push potentiometer down through hole, and pull out at an angle.

### STEP 5:

Install new potentiometer.

Install new potentiometer by repeating these 4 steps in reverse order.

